

DISPLACEMENT CALIBRATOR



The displacement calibrator is used for calibrating dial gauges or displacement transducer.


It come with 2 holders of size 8mm and 19mm diameter for general use.
A micrometer is Designed as the referencev.



Model	G-010
Made	Thailand (Geo- Integration)
Range	0-25mm
Resolotion	0.01mm

Equipment supplied includes

- 1) Adjustable Frame
- 2) 2 holder for displacement tranducers dial gauges
- 3) Hex socket key



GEO INTEGRATION CO.,LTD
39/165,167 MOO,13 CHOKECHAI 4 ROAD
SOI69,LAPHRAD,BANGKOK 10230
TEL: (02) 931-1545/FAX: (02) 931-0743
E-MAIL: sales@geo-integration.com
WWW.geo-integration.com

บริษัท จีโอ อินทิเกรชั่น จำกัด
39/165,167 หมู่ 13 ถ.โชคชัย4 ซอย69
แขวงลาดพร้าว เขตลาดพร้าว กรุงเทพฯ 10230
โทร: (02) 931-1545/แฟกซ์: (02) 931-0743
E-MAIL: sales@geo-integration.com
WWW.geo-integration.com